

pressure intelligence

Installation (GB)
Installation (F)
Einbauleitung (D)
Installazione (I)
Instalatie (NL)
Instalação (P)
Instalacion (E)
Installation (S)
Установка (RU)

Milli-Gard (MIL)

Elfab Limited
Alder Road, North Shields, Tyne and Wear, NE29 8SD
UNITED KINGDOM
e-mail: sales@elfab.com / www.elfab.com
Tel: +44(0)1912931234

Elfab China Chinasales@elfab.com
Elfab Poland Polandsales@elfab.com
Elfab Singapore Singaporesales@elfab.com

1

2

3

4

(GB) Do not use if damaged

(F) Ne pas utiliser si endommagé

(D) Niemals beschädigte berstschelbe einbauen

(I) Non utilizzare se danneggiato

(NL) Indien beschadigd niet gebruiken

(P) Não usar se avariado

(E) No utilice en caso de que este dañado

(S) För ej användas, om det är skadat

(RU) Не пользоваться при повреждениях

5

P

T

MIL

HLD-REV ✓

6

7

POSITIVE PRESSURE

NEGATIVE PRESSURE

8

9

Φ T P

DRAWING NUMBER	00-00-09023	REVISION	0
----------------	-------------	----------	---