



elfab pressure intelligence

Installation (GB)
 Installation (F)
 Einbauanleitung (D)
 Installazione (I)
 Installatie (NL)
 Instalação (P)
 Instalación (E)
 Installation (S)
 Установка (RUS)

Tank Safe (TSD/TSF)


Elfab Limited
 Alder Road, North Shields, Tyne and Wear, NE29 8SD
 UNITED KINGDOM
 e-mail: sales@elfab.com www.elfab.com
 Tel: +44(0)1912931234

Elfab China Chinasales@elfab.com
 Elfab Poland Polandsales@elfab.com
 Elfab Singapore Singaporesales@elfab.com


1



2




3




4


(GB) Do not use if damaged (P) Não usar se avariado
 (F) Ne pas utiliser si endommagé (E) No utilize en caso de que este dañado
 (D) Niemals beschädigte berstschelbe einbauen (S) För ej användas, om det är skadat
 (I) Non utilizzare se danneggiato (RUS) Не пользоваться при повреждениях
 (NL) Indien beschadigd niet gebruiken




5




6




7




8



9



Refer to flange and fastener manufacturer's data.



Torque Wrench

DRAWING NUMBER

00-00-09027

REVISION

0